

Manual

Total RNA Zol-Out[™] D

Kit for the rapid purification of ultra-pure total RNA from samples prepared in (TRIzol® TRI Reagent®, RNAzol®, QIAzol®, TriPure ™, TriSure ™, etc.). Includes on-column DNA digestion.

catalog #	size
043-25	25 isolations
043-100	100 isolations

Guarantee

A&A Biotechnology provides a guarantee on this kit.

The company does not guarantee correct performance of this kit in the event of:

- not adhering to the supplied protocol
- not recommended use of equipment and materials
- the use of other reagents than recommended or which are not a component of the kit
- the use of expired or improperly stored reagents and columns



Table of contents

Contents	3
Additional equipment and reagents Necessary	3 3
Important notes	3
Material preparation	4
DNA digestion solution preparation	4
Isolation protocol	5
Safety information	7

Contents

	2	25 isolations	100) isolations	
component	quantity	cat#	quantity	cat#	storage
microcolumns	25 pcs	K-C02-25	100 pcs	K-C02-100	15-25 ℃
2 ml tubes	25 pcs	K-PC-25	100 pcs	K-PC-100	15-25 ℃
1.5 ml elution tubes	25 pcs	K-C01P-25	100 pcs	K-C01P-100	15-25 ℃
A2WE wash solution	45 ml	K-A2WE-45	180 ml	K-A2WE-180	15-25 ℃
R8I wash solution	20 ml	K-R8I-20	80 ml	K-R8I-80	15-25 ℃
DNAse	220 µl	K-DNA-220B	650 µl	K-DNA-650B	-20 °C
10x DNAse buffer	1.5 ml	K-BDNA-15A	1.5 ml	K-BDNA-15A	-20 °C
ultrapure water	8 ml	K-WUP-8	30 ml	K-WUP-30	-20-25 °C

The binding capacity of the RNA purification column is $10 \,\mu g$ of RNA.

Additional equipment and reagents

Necessary

- 1.5 ml sterile tubes
- 96-99% ethanol
- microcentrifuge
- heatblock set to 50 °C

Important notes

When working with RNA, use RNAse-free consumables. Work sterile, use disposable gloves and change them whenever good laboratory practice requires it.

Material preparation

1.	Add 1/3 volume of ultrapure water t o 1 volume of the sample suspended in TRIzol [®] (e.g. to 300 µl of TRIzol [®] suspended cells add 100 µl of ultrapure water).
2.	Close the tube and mix by inverting the tube a few times.
3.	Centrifuge the sample for 10 min at 10 000 RPM .
4.	Transfer the supernatant to a new 1.5 ml tube (not included).
5.	Add 1 volume of 96%-100% ethanol (not included) to 1 volume of the supernatant (e.g. add 350 μ l of ethanol (96-100%) to 350 μ l of the supernatant).
6.	Close the tube and mix by inverting the tube a few times.
7.	Follow point <u>1. of the protocol</u> .

DNA digestion solution preparation

Before proceeding to RNA isolation, prepare the appropriate amount of DNA digestion solution according to the following formula (50 μ I of solution per sample):

component	volume per 1 sample	volume per 25 samples	volume per 100 samples	n - sample quantity
10x DNAase buffer	5 µl	26 x 5 µl	101 x 5 µl	(n+1) x 5 µl
	+	+	+	+
DNAse	6 µl	26 x 6 µl	101 x 6 µl	(n+1) x 6 µl
	+	+	+	+
ultrapure water	39 µl	26 x 39 µl	101 x 39 µl	(n+1) x 39 µl
	=	=	=	
DNA digestion solution	50 µl	1,3 ml	5,05 ml	

Mix and describe "DNA digestion solution"

Isolation protocol

If sample volume is greater than 700 µI repeat point 1. and 2. of protocol discarding flow-through after each repetition.

1.	Apply a maximum 700 µl of prepared material onto the microcolumn.
2.	Centrifuge for 1 min at 10 000 RPM .
3.	Apply 700 µl of the A2WE wash solution onto the microcolumn.
4.	Centrifuge for 2 min at 10 000 RPM .
	Attention. It is necessary to centrifuge min. 2 min to remove ethanol from the microcolumn membrane.
	On-column DNAse digestion
5.	Transfer the microcolumn to a new 2 ml tube (included).
6.	Add 50 µl of DNA digestion solution directly onto the microcolumn membrane, ensuring no droplets remain on the column inner walls or membrane-securing ring.
7.	Incubate for 30 min at 37 °C .
8.	Add 700 µl of R8I wash solution.
9.	Centrifuge for 1 min at 10 000 RPM .
10.	Collect the filtrate from the tube and apply it again onto the microcolumn. Place the microcolumn into the same tube.
11.	Centrifuge for 1 min at 12 000 RPM .
12.	Discard the filtrate from the tube. Place the microcolumn into the same tube.
13.	Add 700 µl of A2WE wash solution.
14.	Centrifuge for 1 min at 10 000 RPM .

15.	Discard the filtrate from the tube. Place the microcolumn into the same tube.
16.	Add 200 μl of A2WE wash solution.
17.	Centrifuge for 2 min at 10 000 RPM .
	Attention. It is necessary to centrifuge min. 2 min to remove ethanol from the microcolumn membrane.
18.	Transfer the microcolumn to a new 1.5 ml elution tube (included).
19.	Add 40 µl of ultrapure water .
20.	Keep for 3 min at room temp .
21.	Centrifuge for 1 min at 10 000 RPM .
22.	Remove the microcolumn, close the elution tube with the purified RNA. Store at -20, -80°C until later use.

Safety information

\wedge	A2WE wash solution
DANGER	H225 Highly flammable liquid and vapor. H319 Causes serious eye irritation. P210 Keep away from heat, sparks, open flames, hot surfaces. No smoking. P233 Keep container tightly closed. P305+P351+P338 If in eyes: rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
• •	R8I wash solution
	H225 Highly flammable liquid and vapor.
	H319 Causes serious eye irritation.
	H319 Causes serious eye irritation. H336 May cause drowsiness or dizziness.
DANGER	H319 Causes serious eye irritation.



A&A Biotechnology, ul. Strzelca 40, 80-299 Gdańsk, Poland phone +48 883 323 761, +48 600 776 268 info@aabiot.com, www.aabiot.com

version 2025-1

